



More than just control



Do you SHOCKO your process?

SYNCRO is the ideal partner for plastics processors who require innovative technology to gain a competitive edge. We provide reliable process control products, paired with fast service and support.

Based in Italy, SYNCRO has four branch offices throughout Europe, Asia, and South America. Joint ventures have been established in North America, Latin America, and Asia.

Our rapid growth is attributed to our professional team members "The SYNCRO Family" who design flexible solutions to meet our customer's needs.

At SYNCRO, our success is based on your success!



The World syncronized



Web www.plusmarine.com


E-mail info@plusitaly.eu

Phone +55.11.29966653

E-mail latina@syncro-group.it

syncro-group.it





SHINI-SYNCRO extrusion control, LTD China

Dalang, Dongguan, Guangdong - China Phone +86.769.8267.7669 Fax +86.769.8267.7663

E-mail dongguan@shini-syncro.com



SHINI-SYNCRO extrusion control, LTD Taiwan

Minhe Street, Shulin City,

Taipei, Taiwan

Phone +886.2.2680.9119 Fax +886.2.2680.9229 E-mail taipei@shini-syncro.com



SHINI-SYNCRO extrusion control, LTD India

Village: Waliv Tal. Vassai, Dist: Thane, India Phone +91.96.2345 2250 Fax +91.96.2345 2257 E-mail india@shini-syncro.com

STUCROservice

JR Servicio Tecnico

C/Livia, n°7 08748 Cervellò – Barcelona Phone +34.609.751935 E-mail josep@syncro-group.it

SYNCROservice

SKÅNSK ELTEKNIK AB

Hammarvägen 1 ARLÖV - SVERIGE23237

Phone +46.40.432266 Fax +46.40.430308

E-mail anders@syncro-group.it

SYNCROservice 🧻

PS Plastic Services Latin America

Km 31, Carretera a Sonsonate, Sacacoyo, La Libertad El Salvador Phone +503.71296719

E-mail juanjose@syncro-group.it







FI-Per AUTO, is the new SYNCRO PATENT PENDING automatic air ring designed for high efficiency and high output. Elevators lift up the automatic upper four lip air ring almost doubling the line throughput while improving physical proprieties of the film as per tear, haze, elongation and especially dart drop.









				-	
100	and5	endytist	T-rty		W 5-5
-1111				<u>;:B</u>	
-	1111	-	-	mile:	
_				11111	

		Tradizional Air Ring	FlYer	Range of Values
Die diameter	mm	350	350	
2° air ring diameter (Virtual die)	mm		445	
Ratio die / Virtual die	-		1,27	(1,15-1,30)
Film thickness	μm	70	70	
Lay Flat	mm	1905	1905	
BUR 1 (Bubble diam / 2° Air ring)	-		2,73	(1,7-3,0)
BUR 2 (Bubble diam / Die diam)	-	3,47	3,47	(3,5-5,0)

Type of material	K kg / (h mmØ)	Output (kg / h)	Output (kg / h)	K kg / (h mmØ)	Output/Output %
100% LDPE	1,05	367	734	2,10	200,2
50% LLDPE (C6-C8) + 50% LDPE	0,91	319	639	1,83	200,2
75% LLDPE (C6-C8) + 25% LDPE	0,87	304	609	1,74	200,2
100% LLDPE (C6-C8)	0,78	271	543	1,55	200,2
100% LPDE (C4)	0,77	268	536	1,53	200,2


When **flucr** is raised to the upper position where the bubble expansion is greater, it provides efficient cooling over a larger surface. Simple start-up and die cleaning are added benefits of the vertical adjustment. Fiver AUTO provides segmented airflow to localized areas around the blown film bubble through the air ring while stabilizing the film exit due to the forth special downward **fiver** lip. This automatic thickness improvement system offers simplicity and state-of-the-art visualization giving the highest operational reliability. The system effectively increases the low areas in the film to improve quality and yield.




duplex; is the new SYNCRO stacked automatic air ring for high efficiency and high output. Elevators lift up the automatic upper three lip air ring to increase the line throughput almost doubling the output while improving physical properties of film as per tear, haze, elongation and especially dart drop.



When **duplex**: is raised up to the upper position where the bubble expansion is greater so cooling becomes more efficient over a larger surface. **duplex**: provides segmented airflow to localized areas around the blown film bubble through the air ring, while stabilizing the film exit due a lower single lip air ring.









SEMPTO AUTO is a completely automatic system for the on-line thickness profile control. The air flows of the segmented disk integrated into the air ring are controlled by stepper motors which adjust the opening/ closing of the gates.

5pro AUTO






The thickness measuring system is integrated into the supervision software and supplies **SYPro AUTO** with the measured profiles.

When measuring a point having a thickness higher than the set tolerance, the stepper motor will decrease the air flow into the corresponding segment, thus reducing the film thickness, while, when measuring a point with a thickness lower than the tolerance, the air flow is increased in order to increment the thickness.







ea54flow

cooling air ring which offers a fine adjustmentof air volume to control the lip set.

Characteristics:

- ♥ Upgradable to automatic control in the future
- **♀** Adjustable lips
- ₩ 6/8 air inlets
- ♥ Interchangeable lip-set
- ♣ Aluminium casting construction



syncro-products.it/easyflow







5th pro MAN

trol system for the profile: by simply integrating a segmented disk with the standard air ring, it is possible to manually adjust the air flow in the different segments thanks to dedicated screws/gates.


The operator, after checking the film thickness off-line, can adjust the opening of every single gap of the segmented disk and regulate the air flows, thanks to which the profile is regulated. It is particularly suitable for those installations which do not require a frequent production change.



syncro-products.it/syproman



optumex, patent NON CONTACT gauging system based on NIR reflex technology for blown film. **optumex** provides a continuous measuring of material thickness. Installed on an oscillating ring it is able to refresh the profile every 2-3 minutes, uninfluenced by the haul off speed.





The sensor can be used to measure total thickness of materials for which the component r2 has sufficient optical intensity to provide the interference signal, transparent or semi-transparent materials. Colored material can also be measured under certain conditions. It is also possible to measure materials on metal substrates because the metal base is reflective.

Utilizing modular technology, optemex ensures simple, practical operation by providing the operator with all the information required to operate the system clearly and intuitively using a touch screen HMI.





SYNCRO **comb**: scan, patented measuring system based on non-contact inductive/capacitive technology. The new sensor combY is composed by an Inductive/capacitive sensor which allows the measurement of either sheet and/or film's thickness using a cylinder as a contrast.






CombY uses the inductive technology to measure the distance between sensor, cylinder feedback and one second capacitive sensor which, pending measurement of dielectric material, provides a more accurate thickness value.

For a blown film line **comb**: scan be installed after the haul-off and the SYNCRO patented software will be able to measure the flattened film and calculate the profile quickly, prior to a complete rotation of the haul-off.

Utilizing modular PLC technology, combuscan ensures simple, practical operation by providing the operator with all the information required to operate the system clearly and intuitively using a touch screen HMI.







It can be installed either stand alone on the collapsing frame or on an oscillating ring connected to an auto profile control. easing is available in either contact or NON contact versions for materials considered sticky and/or delicate.






Utilizing modular technology, east mex ensures simple, practical operation by providing the operator with all the information required to operate the system clearly and intuitively using a touch screen HMI.

5 + head

contact technology. It is installed after the haul-off unit and measures the thickness of one edge of the flat film, thus obtaining the complete profile whenever the take-off unit oscillates 360°.









Bubble stability control

manage blower balance while coordinating all blower control functions. Stibc is equipped with an ultrasonic distance sensor to be installed on the bottom part of the cage on the movable arms to keep the gap constant between sensor and bubble. Optional additional ultrasonic distance sensors can be installed above the cage where the bubble is already formed to

control lay flat and automatic opening/closing of the cage. The customized control valve provides the fine tuning necessary for high precision and accuracy in bubble stability and lay flat control. Utilizing modular technology, sibc ensures simple, practical operation by providing the operator with all the information required to operate the system clearly and intuitively using a touch screen.











Lay flat control

Fine tuning valve



Patented by SYNCRO, optwscan represents the latest film measuring technology on the market.

Main advantages versus current competing technology:


- ₩ NIR technology, based on interferometer concept avoiding any bureaucratical procedure.
- Optical technology has a small, 1 mm measuring area, much more accurate than IR, X-ray or Beta-ray whose measuring area can be higher than 10 mm.
- Optical is backscatter so it doesn't require a receiver.
- Optical doesn't care if film is moving up and down or of any particularly vibration, quality of measure will be kept the same.
- Thanks to the unique installation on the chill roll, optYscan will guarantee a faster response in auto profile control due to its proximity to the die. This is important during start-up where each meter of film extruded is important.














TECHNICAL SPECIFICATION	VERSION			
	EP1	EP2	EP3	
Max thickness (1)	100µm	380µm	1800µm	
Opical source	Halogen Lamp	SL	.D	
Accuracy (2)	← 0,1 micron			
Measuring time (3)	← 10 ms			
Spot dimension	~ 3 mm ~ 1 mm		mm	
Working range	30-50 mm	35-45 mm		




The optical sensor is based on low coherence interferometry. The material is illuminated with a broadband near-infrared light source; part of this light is reflected at the air/material interface (component r1).

Part of the light that travels through the material is then reflected in correspondence of the material/air boundary (component r2).

The optical head collects both r1 and r2 and disseminates information between the two components.

The resulting optical signal intensity has an oscillatory component with a frequency f, called optical thickness, given by f = 2nd, where d is the thickness and n is the refractive index of the material.

Measuring f and knowing n, the thickness d can be obtained with high accuracy.



The sensor can be used to measure total thickness of materials for which the component r2 has sufficient optical intensity to provide the interference signal, like transparent or semitransparent materials; colored material can also be measured under certain conditions.

It is also possible to measure materials on metal substrates because the metal base is reflective.



5 + scan A

SYNCRO family of measuring systems. **SYNCRO** is composed of a mechanical scanner suitable to measure film of different widths and is complete with microprocessor electronics with Ethernet network interface.



ing principle, such as the inductive measuring system of the distance. System A is composed by two measuring heads which are equipped with compressed air nozzles with a particular patented

geometry, which produces an air cushion having a constant thickness between heads and film so as to allow the film/sheet movement without the contact of the heads and without marking the extruded product.

ra\u00a4xcan

syncro-products.it/ rayxcan



SYNCRO rawxcan, is a revolutionary new gauge which measure the thickness and weight of foils, sheets, films of any type of material without



radiation. The X-ray backscatter sensor raYx is based on the measurement of Compton rays, scattered by the material being measured. Compton rays are very similar to beta rays in that their absorption is relatively insensitive from chemical composition.

They have the great advantage to be generated from a tube and do not suffer therefore the costs and the limitations due to the use of radiation. In addition the raYx is mounted on a single sided traversing frame and it offers advantages of cost and space.

SYNTROLgauge


SYNCRO auto die system to control automatically the thermal cartridge in the flat die to regulate the film/sheet thickness being able to modify mechanically the flat die lip.

Due to the smart control special die mapping will allow the system to consider material neck-in, neck-out and bumping to achieve a better auto die control to get always the best product.










SWITTCLgauge auto profile control meets application also on blown film line process.


It can be interfaced on OEM die with thermal cartridge heaters to modify the die lip opening/closing according to the target thickness.





It can also be interfaced to auto air ring with cartridge heaters internally installed where according to the profile set the air temperature will be modified accordingly.



Based on commercial modular PLC electronics, SWITROLgauge ensures simple, practical operation by providing the operator with all the information required to operate the system clearly and intuitively using touch screen HMI on board. In blown film application SWITROLgauge would be controlled and connected to any of the SYNCRO gauging system for blown film line.












Simple of the property of the multaneously for all processes where a homogeneous mix is critical to achieving an excellent final product. **Second in the proof of the proof of the process as per BCF, FDY and POY.** Each hopper and material is weighed by two off-center load cells.









Based on commercial modular PLC electronics, **Syblend** ensures simple, practical operation by providing the operator with all the information required to operate the system clearly and intuitively using touch screen HMI on board.

Process control software **54blend**:


- **♥** Loss in weight control
- ♥ Gram/metre and throughput control
- Materials consumption
- 😛 Alarms

Still dos is a continuous loss in weight gravimetric dosing system designed to dose and feed multiple components simultaneously in all processes in which a constant gravimetric feeding is required. Each hopper and material is weighed by two off-center load cells.

Utilizing modular PLC technology, sensures simple, practical operation by providing the operator with all the information required to operate the system clearly and intuitively using a touch screen HMI.

Process control software **Structure**:

- **↓** Loss in weight control
- Material consumption
- **#** Alarms











strict is the revolutionary and patented loss in weight gravimetric batch blender designed to dose and blend multiple components simultaneously in all processes in which a constant gravimetric feeding and a homogeneous mix is required.





Innovative logic and design make **substantial** a unique system solving most of the problems with classic gain in weight batch blender technology.

Utilizing modular PLC technology, Sybatch ensures simple, practical operation by providing the operator with all the information required to operate the system clearly and intuitively using a touch screen HMI.

Process control software **Struct**:

- **↓** Loss in weight control
- Material consumption
- **#** Alarms

ea5#batch

eas whatch is the traditional gain-in-weight batch blender, designed to dose and blend multiple components in sequence for all processes where constant gravimetric feeding and a homogeneous mix is required.







Utilizing modular PLC technology east batch ensures simple, practical operation by providing the operator with all the information required to operate the system clearly and intuitively using a touch screen HMI.

Process control software eas#batch:

- Loss in weight control
- ♥ Gram/meter and throughput control
- ₩ Material consumption
- **#** Alarms








Signal is a gravimetric loss in weight hopper designed to gravimetrically feed the extruder throat controlling the throughput set.

The weight hopper and relative material is weighted by two off-centre load cell.





Based on commercial modular PLC electronics, **Styline** ensures simple, practical operation by providing the operator with all the information required to operate the system clearly and intuitively using touch screen HMI on board.

Process control software **Still**:

- Loss in weight control
- **♀** Gram/meter and throughput control
- ➡ Material consumption
- Alarms

SYNCRO has developed stand alone and centralized conveying system to be automatically integrated into all the SYNCRO blenders Family. Based on commercial modular PLC electronics, Sylink & Sylink electronics, simple integration along with all SYNCRO machines.







SYNTROLplus



SYMPACIFIES is a complete supervisory system designed to control existing or new complete extrusion blown film line. SYNCRO provides complete system [15] PLC based control on either mono or coextrusion blown line **SYNTROLplus** series.





SYNTROLDIUS SCADA 15" PLC includes:

- **♥** Electrical panels for temperatures and pressure control
- ₩ Electrical panel for power and drives control
- ₩ Air conditioned for cabinet temperature control
- ➡ Temperature control of all heat/cool and heat only zones
- ♣ Speed control of all extruders drivers
- ₩ Blenders and yield control
- Centralized conveying system and material handling

- ♥ IBC control & Lay flat control
- ➡ IBC % Air Ring blowers control
- ₩ Bubble cage open/close & raise/lower control
- ♥ Open close collapsing frame
- ♥ Gauging system control
- ₩ Automatic air ring or auto die control
- Oscillating nip left/right control
- Oscillating nip open/close control
- ♥ Secondary nip open/close control
- ➡ Alignment control
- Auxiliary equipment control















SYNTROLplus






SYNTROLremote

SYNCRO machines via Ethernet to the customers office to allow production management to control the line's production and prepare the following jobs.

Based on commercial modular PLC electronics, SPITROL ensures simple, practical operation by providing the operator with all the information required to operate the system clearly and intuitively using touch screen HMI on board.










The automatic Rewinder $\bigcirc \bigcirc \bigcirc$ is the status of art of automatic rewinder for the production of Stretch Cling Film for manual and automatic use. The machine is multipurpose being able to produce coreless and conventional paper core reels.




The internal diameter of the reel will be 2" or 3" in both cases. Thanks to the user friendly human interface operator can easily set the production parameters: meters or weight, speed, tension, contact force, taper function, etc. The project, focused on the control of the tension from the first layer up to the end of the reel index included is based on brushless synchronous motors with digital drives and proprietary software managing dedicated functions to set the speed of the motors and monitoring the real web tension by load cells. The machine is prepared to add a pre-stretching unit with special coated rolls and brushless motors.

The patent pending shaft is a mechanical collapsible shaft which is perfectly round when expanded once collapsed the perimeter of the body is reduced of about 10%. This means: zero tension so that is not required to remove the shaft after winding.

As option **€⊂□≤∵** can be equipped with :

- **₩** Edge reinforcement
- Oscillating system
- ➡ Film break sensor
- ₩ Finished rolls conveyor
- ₩ Weight per meter control











Syncro-group.it

